



Adjust the unloaded charger output to 177VDC

After making the connections to the battery, turn on the battery disconnect switch, turn on the charger power, and you will see the voltage rise as the pack charges. When the Voltage stops rising and is stable or starts to drop, the pack is full. On the first charge, let it soak for 12 hours. Always run the pack cooling fan.

Title		Insight grid charger/balancer	
Size	Document Number	Mike Dabrowski	Rev
A	<Doc>		1
Date:	Mar 8 2012	Sheet	1 of 1